



Short Shift Kit For; 924/944/968

Removal.

- 1, Lift leather gear gator & surround.
- 2, lift rubber inner gator.
- 3, release hair grip pin at base of lever.
- 4, Pull gear knob up vertically to remove. Note; this may take some effort.
- 5, Remove 'C' clip & release the old lever from the selector shaft.
- 6, Using a 13mm socket & extension bar push down through the sound deadening foam to access the two securing bolts.
- 7, carefully remove these bolts taking care not to drop them under the car.
- 8, lift out the lever assembly & pop off the nylon cup & plate.

Re-fitment

- 1, Place the nylon cup & plate on the new ball.
- 2, Secure the lever back into place with the two 13mm bolts.
- 3, remove the 'C' clip & re fit the selector shaft.
- 4, adjust the lever to the length required by removing the selector shaft & pin and rotation the lever until the desired position is set.
Note; Make sure there is clearance in all gears to the tunnel once set in place.
- 5, Replace the rubber gator.
- 6, Re fit the two small rubber grommets to the new shaft & replace the leather gear gator & surround along with the hair grip pin at base of lever.
- 7, re-fit leather gator surround.