



CDA Induction Kit for 911/ 993 C2/C4 3.6 Years 1994-1997 (For Non Aircon cars only)

- 1 Unclip air box cover and remove air filter
- 2 Remove air box by unscrewing 10mm bolts
- 3 Fix the 90 degree silicone hose to airflow meter facing rearward
- 4 Using bracket supplied fix one end to the CDA strap and other end to the cotton reel mounting boss on the inlet manifold, allowing the CDA to face rearward.
(You may need to shape bracket as required)
- 5 Fit the silicone collar to the engine side of the CDA and using the black hose supplied, shape into a 90 degree loop And cut to length using either a hacksaw or Stanley knife. The hose should fit over the adaptor collar and inside the silicone collar, these should be secured with Jubilee clips.
(Note; washing up liquid will help ease of fitting & clean silicone hose too)
- 6 Using the remaining piece of black hose supplied, curve this into 45-120 degrees and fit to the inlet side of the CDA ensuring it faces downwards and away from the engine fan & lid.

NB: Filters are pre-oiled and will only need cleaning and re-oiling every 24,000 miles.