



996/997 Highflow Induction Kit.

- 1, Open rear lid and access engine bay
- 2, Undo the 3 clips holding the factory air intake boot.
- 3, Carefully remove the factory air intake boot & clips.
- 4, Slide the 2 existing large clips onto the new intake hose.
- 5, Carefully install the new intake hose, making sure there is a good seal between the throttle body & air box & tighten the clips.
- 6, Now you are ready to install the red block-off cap onto the open hole on top of the air box.
- 7, Using the 1 remaining small clip from the old factory hose tighten this over the red block-off cap over the open hole on top of the air box.

FOR 3.6 (2001-2008) TIPTRONIC CARS ONLY.

Once assembled drill a 4mm hole into the side of the hose adjacent to the vacuum pipe and insert vacuum pipe.

- 8, Now you are ready to start your engine.

Note.

If your car has a faulty air mass sensor the induction kit will make this more noticeable due to increased air flow. This can be detected if there is a slight hesitation in the power band between 4-5,000 rpm whilst accelerating under normal load. You will see this sensor on the air box and is easily replaced should this be the case. The sensor can be ordered separately by going to; www.porscheshop.co.uk